





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA, AD...



- 6 A 860 808 XX
- 20 A 4109 XX
- 21 B 9403 XX
- 23 A 860 807 XX
- 25 A 860 806 XX
- 29 B 9442 XX
- 30 A 860 843 XX



IDEALDUO

A 5689 ..

0513 / A 866 429
 (+ A 865 612)
 Made in Germany
















Ideal Standard International BVBA
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





1
↓
20



	P bar				Q (3 bar)
	T °C				
					8
					11